



Galvatech

ZINC SPRAY

Technical Info

- Temperature resistance: +315°C.
- Drying times:
 - dry after 3 minutes.
 - water resistance after 15 minutes.
 - second layer after 15-30 minutes.
- Can be repainted: after 24 to 48 hours (with the majority of paints).
- Full hardening: after 14 days.
- Accelerated hardening: 30 minutes at 150°C.
- Shelf life: 36 months, keep dry, cool and frost-proof.
- Safety measures: consult the Safety Data Sheet.

Packing

Galvatech - aerosol 400ml

901112000

Product

Characteristics

Metal spray with 95% pure zinc powder for cold galvanization of all metals. Fast drying and waterproof after 10 minutes, can be painted after 12 hours at room temperature.

Applications

- Renovation or finishing of hot galvanized surfaces, damaged by welding, drilling or cutting.
- Anti-corrosion layer on steel structures. Protection of welded parts, structures, ...

Use

- Sand first if necessary.
- After releasing the mixing ball, shake well before use.
- Apply from ± 30 cm on a clean, dry and rust-free surface.
- 2 thin layers give the best results.
- After use, empty the nozzle, spraying with the can upside down.