

Fiberglass Tape

REINFORCING, SELF-ADHESIVE REINFORCEMENT TAPE FOR AQUASTOP LIQUID & AQUASTOP PASTE

✓ Also suitable for drywall, polyester, synthetic resin, etc.



Technical Info

Packing

Fiberglass Tape - roll 24 x 20m - width 50mm 590907000

Product

Characteristics

Use Fiberglass Tape in areas where reinforcement is required:

- Indoor and outdoor angles
- Transitions between structural elements
- Joints and cracks

Use

- Seal seams and cracks with Aquaseal.
- Apply the grey Aquastop Paste immediately after.
- Press the Fiberglass Tape gently into the top layer.
- Immediately cover everything with at least 2 mm of grey Aquastop Paste.
- For more information, please refer to tec7.be/aquastop